



HYTORC AVANTI - .7

PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI				PRESSURE IN
	FT. LBS.	KGM	NM	BAR
1500	103	14	140	104
1600	110	15	149	110
1800	125	17	169	124
2000	139	19	188	138
2200	154	21	209	152
2400	168	23	228	166
2600	183	25	248	179
2800	197	27	267	193
3000	212	29	287	207
3200	227	31	308	221
3400	242	33	328	235
3600	256	35	347	248
3800	271	37	367	262
4000	286	40	388	276
4200	301	42	408	290
4400	316	44	428	304
4600	331	46	449	317
4800	345	48	468	331
5000	360	50	488	345
5200	375	52	508	359
5400	391	54	530	373
5600	406	56	550	386
5800	421	58	571	400
6000	436	60	591	414
6200	451	62	611	428
6400	466	64	632	442
6600	481	67	652	455
6800	496	69	672	469
7000	511	71	693	483
7200	526	73	713	497
7400	542	75	735	511
7600	557	77	755	524
7800	573	79	777	538
8000	588	81	797	552
8200	604	84	819	566
8400	620	86	840	580
8600	635	88	861	593
8800	651	90	882	607
9000	667	92	904	621
9200	682	94	925	635
9400	697	96	945	649
9600	713	99	967	662
9800	728	101	987	676
10000	744	103	1009	690

This chart supercedes all prior version regarding this tool

03/31/2008

MAIN OFFICE	SOUTH TEXAS OFFICE	WEST TEXAS OFFICE	EAST TEXAS OFFICE
12420 TEXACO RD	4802 BALDWIN BLVD	3508 S. COUNTY RD 1290	2484 W. CARDINAL AVE #4
HOUSTON, TX 77013	CORPUS CHRISTI, TX 78408	ODESSA, TX 79765	BEAUMONT, TX 77705
713-453-6677	361-888-5080	432-561-8481	409-840-9699